

## **Temperature sensor DX1111**



DX1111 temperature sensor is designed for use in the normal space, for measuring the temperature in the rooms.

The sensing element (Pt1000) is placed on printed circuit boards (measuring module), which is also a terminal block for connecting the wires used to connect the sensor to the controller and a jumper to calibrate the sensor (offset the impact resistance of the wires - after calibration needs to disengage).


The module is placed in a plastic housing with ventilation holes. Case is placed flush-mounted to the wall box.

- Sensor Pt1000
- Flush mounting
- Linear transfer
- Long-term stability
- Reliability

| Temp [°C] | R [Ω]  |      |    |
|-----------|--------|------|----|
| -30       | 882,2  | 1500 | 7  |
| -20       | 921,6  | 1400 | -  |
| -10       | 960,9  | 1400 | 1  |
| 0         | 1000,0 | 1300 |    |
| 10        | 1039,0 |      |    |
| 20        | 1077,9 | 1200 | -  |
| 30        | 1116,7 |      |    |
| 40        | 1155,4 | 1100 | +  |
| 50        | 1194,0 |      |    |
| 60        | 1232,4 | 1000 | 1  |
| 70        | 1270,7 |      |    |
| 80        | 1308,9 | 900  | 1  |
| 90        | 1347,0 | 800  |    |
| 100       | 1385,0 |      | 10 |
| 110       | 1422,9 |      |    |

## **Technical data**

Measuring component Mechanical dimensions Measure range Measure accuracy PT1000 84 x 84 x 27 mm -20°C až 100 °C 0,5%



DUEL Námestovo s.r.o., Florinova 928/9, 029 01 Námestovo

tel: +421 43 5591092 fax: +421 43 5591091